Sec. 2.23. Weights

A. Application

- **A.1.** This code applies to commercial weights; that is, weights used in connection with commercial weighing devices.
- **A.2.** This code does not apply to test weights or to other "standards" of mass.
- A.3. See also General Code requirements.

S. Specifications

- **S.1. Material.** The material used for weights shall be as follows:
- (a) Weights of 6 g or 100 gr and larger shall be made of a metal, or a metal alloy, not softer than brass.
- (b) Weights of less than 6 g or 100 gr may be made of aluminum, but shall not be made of iron or of unplated steel, except stainless steel.

S.2. Design.

- **S.2.1. Surface.** The surface of a weight shall be smooth and shall not be coated with thick, soft, or brittle material. A weight of more than 2 g or 30 gr or shall not have sharp edges, points, or corners.
- **S.2.2. Ring.** A ring on a weight shall not be split or removable.
- **S.3.** Adjusting Material. Adjusting material shall be securely positioned and shall not project beyond the surface of the weight.

S.4. Marking Requirements.

- **S.4.1. General.** A weight shall be marked to show clearly its nominal value, which shall include identification of the unit; however, the nominal value of a weight of 30 gr or 2 g, or less, may be designated by dots, lines, figures, distinctive shape, or other appropriate means.
- **S.4.2. Apothecaries' Weights.** On apothecaries' dram, ounce, and pound weights, the letters "ap" shall be used

- in combination with the nominal value and the appropriate abbreviation of or symbol for the unit.
- **S.4.3. Troy Weights.** On troy ounce and pound weights, the letter "t" shall be used in combination with the nominal value and the appropriate symbol of the unit.
- **S.4.4. Metric Weights.** On metric weights, the symbols "kg," "g," and "mg" shall be used in combination with the nominal value of kilograms, grams, and milligrams, respectively.
- **S.4.5.** Carat Weights. On carat weights, the letter "c" shall be used in combination with the nominal value.
- **S.4.6.** Counterpoise Weight. A counterpoise weight shall be marked to show clearly both its nominal value and the value it represents when used on the multiplying-lever scale for which it is intended.

N. Notes

N.1. Testing Procedures. - Commercial weights should be tested on a precision balance using standard weights, the errors of which, when used without correction, do not exceed 1/3 of the smallest tolerance to be applied. (See Appendix A; Fundamental Considerations paragraphs 3.2. and 3.3.)

T. Tolerances

- **T.1.** In Excess and in Deficiency. The tolerances hereinafter prescribed shall be applied equally to errors in excess and errors in deficiency.
- **T.2.** On Avoirdupois Weights. The maintenance tolerances shall be as shown in Table 1. Acceptance tolerances shall be one-half the maintenance tolerances.
- **T.3.** On Metric Weights. The maintenance tolerances shall be as shown in Table 2. Acceptance tolerances shall be one-half the maintenance tolerances.
- **T.4.** On Carat Weights. The maintenance tolerances shall be as shown in Table 2. Acceptance tolerances shall be one-half the maintenance tolerances.

T.5. On Apothecaries' and Troy Weights. - The maintenance tolerances shall be as shown in Table 3. Acceptance tolerances shall be one-half the maintenance tolerances.

Table 1. Maintenance Tolerance for Avoirdupois Weights Maintenance Tolerance									
Value	For scales with multiples of less than 1000		For scales with multiples of 1000 or over						
OZ	grains	mg	grains	mg	grains	mg			
1/64	0.1	6							
1/32	0.3	19							
1/16	0.4	26							
1/8	0.5	32							
1/4	1.0	65							
1/2	1.5	97	1.0	65					
1	1.7	110	1.0	65					
2	2.0	130	1.0	65					
3	2.0	130	1.5	97					
4	3.0	190	1.5	97	1.0	65			
5	3.5	230	1.5	97	1.0	65			
6	3.5	230	1.5	97					
8	4.0	260	2.0	130	1.5	97			
10	4.0	260	2.5	160	2.0	130			
12	5.0	320	2.5	160	2.0	130			
lb	grains	mg	grains	mg	grains	mg			
1	5.0	320	3.0	190	2.5	160			
2	7.0	450	6.0	390	4.0	260			
3	9.0	580	9.0	580	5.0	320			
4	11.0	710	11.0	710	6.0	390			
5	15	970	12.0	780	6.5	420			
6	17	1190							
7	19	1200							
8	21	1400	15.0	970	9.0	580			
9	23	1500							
10	25	1600	18.0	1160	10.0	650			
15	28	1800							
20	30	1900							
25	35	2300							
30	40	2600							
40	45	2900							
50	50	3200							

Table 2. Maintenance Tolerances for Metric Weights								
Nominal Value (mg)	Maintenance Tolerance (mg)	Nominal Value (g)	Maintenance Tolerance (mg)					
5 or less 10 20 30 50 100 200 300 500	0.1 0.3 0.4 0.6 0.8 1.0 1.5 2.0 3.0	1 2 3 5 10 20 30 50 100 200 300 500	4 6 8 10 15 20 30 40 70 100 150 175					
Nominal Value (kg) 1 2 3 5 10 20	Maintenance Tolerance (mg) 250 400 500 800 1000 1500	Nominal Value (carats) 0.25* 0.5** 1.0 2.0 3.0 5.0 10.0 20.0 30.0 50.0 100.0 *25 points or less **50 points	Maintenance Tolerance (mg) 0.6 1.0 1.5 2.0 3.0 4.0 6.0 10.0 12.0 15.0 25.0					

Table 3. Maintenance Tolerances For Apothecaries' and Troy Weights								
Nominal Value	Maintenanc	e Tolerance	Nominal Value	Maintenance Tolerance				
grains	grains	mg	OZ	grains	mg			
1 2 3 5 10 20	0.01 0.02 0.03 0.03 0.04 0.06	0.6 1.3 2.0 2.0 2.5 4.0	1 2 3 4 5	0.4 0.6 1.0 1.5 1.6	25.0 40.0 65.0 100.0 105.0			
scruples	grains	mg	OZ	grains	mg			
1 2	0.06 0.10	4.0 6.5	6 7 8 9 10	1.8 1.9 2.0 2.1 2.2	115.0 125.0 130.0 135.0 145.0			
dr	grains	mg	OZ	grains	mg			
0.5 1.0 2.0 3.0 4.0 5.0 6.0	0.07 0.10 0.20 0.30 0.40 0.50 0.60	4.5 6.5 13.0 20.0 25.0 30.0 40.0	11 12 20 30 50	2.4 2.5 2.9 3.7 5.4	155.0 160.0 190.0 240.0 350.0			
dwt	grains	mg	OZ	grains	mg			
1 2 3 4 5	0.06 0.10 0.15 0.20 0.30 0.40	4.0 6.5 10.0 13.0 20.0 25.0	100 200 300 500 1000	7.7 12.3 15.4 23.1 38.6	500.0 800.0 1000.0 1500.0 2500.0			